

Vehicle Safety Systems Users Guide

Front Detection

Ignition on

Speakers 'BEEPS' system ready


System in standby when speed above 16km/h (approx.)

System will automatically switch ON when speed drops below 16km/h (approx.)

Digital detection will then start from 0.6m down to 0.3m from the sensor

Stop vehicle if system 'Bleeps' and flashes RED. Object detected

Ignition off, system off



Side detection

Ignition on

Display will flash 'green' to indicate serviceable

System in standby when speed above 16km/h (approx.)

System will automatically switch ON when speed drops below 16km/h (approx.) AND left turn


indicator is applied

External speaker will sound 'Warning Vehicle Turning Left'

This announcement will only sound ONCE

If an object/VRU is detected internal cab display will activate and external siren will continue to sound

Ignition off, system off



Rear Detection

Reverse gear engaged system on

Rear outline marker display will 'Flash' orange TWICE to indicate serviceable

Detection will then start at 2.5m down to 0.45m in three stages

Detection indicated by 3 different Flash rates of the orange strobe

Reverse de-selected, system off